

How to copy the NEP.IMG file to Memory Stick

The following is the procedure to copy the NEP.IMG file to the MS:\mssony\pro\tvconf\prog\ directory of the Memory Stick.

Note: The Memory Stick needs to be formatted with the PCS-1

Prepare the installation material and tools:

- 1) Memory Stick (more than 32Mbyte).
- 2) PC with Windows XX
- 3) NEP.IMG file
- 4) Memory Stick adapter for FDD or USB or PCMCIA Card.

FDD: MSAC-FD2M
USB: MSAC-US1
PCMCIA: MSAC-PC2N

Procedure:

Format the Memory Stick.

- Insert to Memory Stick to the memory stick slot on PCS-1
- Select the MS icon.
- Memory Stick Format? Select "Yes"
- Confirm display "format complete" on screen.
- Remove the Memory Stick from PCS-1

Download software file "VerXX.zip" from website to the PC.

- Un-compress "VerXX.zip" file.
- Double click the "VerXX.zip". The file will auto unzip to "NEP.img"
- Place the formatted MS into your MS adapter of the PC.
- Access the X:\mssony\pro\tvconf\prog\ directory of the Memory Stick.
- Put "NEP.img" file into the "prog" directory (folder).
- MS loading with VerXX is complete.

Upgrade PCS-1 with Memory Stick

- Insert Memory Sick into memory stick slot of PCS-1
- Turn PCS-1 On. The STANDBY lamp will flash. (~2.5 min)
- When loading is completed, the PCS-1 will auto start.
- Remove the Memory Stick from PCS-1
- Verify software version in the information page of the setup menu.

Note: The NEP.img's file version cannot be identified at this time. Make sure the directory where the file is kept after is un-zipped, is labeled with the version number.